


# Compatible Devices for iBox BT LE

Android™	Apple®	BlackBerry®										
<p><b>Requirements:</b></p> <ul style="list-style-type: none"> <li>phones or tablets with OS 2.1 or newer</li> <li>a cellular data plan</li> <li>a current eKEY application downloaded on the device from the Google Play™ Store app</li> </ul>	<p><b>Requirements:</b></p> <ul style="list-style-type: none"> <li>phones or tablets with iOS 4.3 or newer</li> <li>a cellular data plan</li> <li>a current eKEY application downloaded on the device from App Store™</li> </ul>	<p><b>Requirements:</b></p> <ul style="list-style-type: none"> <li>phones or tablets with OS 5 or newer, except the BlackBerry 10</li> <li>a cellular data plan</li> <li>a current eKEY application downloaded on the device from BlackBerry App World™</li> </ul>										
<p>A Supra® eKEY Fob is not required to open the iBox BT device.</p> <p><b>Some Example Devices:</b></p> <p>Droid 2 Droid X EVO™ Galaxy™S4 Galaxy S3 Galaxy Note™ 2 Hero™ Incredible Nexus One™ Nexus™ 4</p>	<p><b>To access the iBox BT LE</b>, the iPhone® (4s and newer), iPad® (4G &amp; 3G), and iPad Mini communicate using Bluetooth® and do not require any additional hardware.</p> <p>Older Apple models (iPhone 4, 3GS, &amp; iPad 2) require a Supra® eKEY Fob or Adapter to open the iBox BT LE. <a href="#">Click here</a> for more Adapter information.</p> <div data-bbox="581 915 1032 1100" style="border: 1px solid black; padding: 5px;"> <p><b>Open an iBox BT LE with:</b></p> <table border="0"> <tr> <td><a href="#">iPhone 6 &amp; 6 Plus</a></td> <td><a href="#">iPad Mini</a></td> </tr> <tr> <td><a href="#">iPhone 5s, 5c, &amp; 5</a></td> <td><a href="#">iPad 4G</a></td> </tr> <tr> <td><a href="#">iPhone 4s</a></td> <td><a href="#">iPad 3G (retina display)</a></td> </tr> </table> </div> <div data-bbox="581 1129 1032 1451" style="border: 1px solid black; padding: 5px;"> <p><b>Use a Supra Fob or Adapter to open an iBox BT LE with:</b></p> <table border="0"> <tr> <td><a href="#">iPhone 4</a></td> <td><a href="#">iPad 2</a></td> </tr> <tr> <td><a href="#">iPhone 3GS</a></td> <td></td> </tr> </table> <div style="text-align: center;">  <p>Supra eKEY Fob      Or      Supra eKEY Adapter</p> </div> </div>	<a href="#">iPhone 6 &amp; 6 Plus</a>	<a href="#">iPad Mini</a>	<a href="#">iPhone 5s, 5c, &amp; 5</a>	<a href="#">iPad 4G</a>	<a href="#">iPhone 4s</a>	<a href="#">iPad 3G (retina display)</a>	<a href="#">iPhone 4</a>	<a href="#">iPad 2</a>	<a href="#">iPhone 3GS</a>		<p>A Supra® eKEY Fob is not required to open the iBox BT device.</p> <p><b>Some Example Devices:</b></p> <p>8800 series Bold™ Touch Curve™ Pearl™/Pearl Flip Storm™ Torch™ Tour™</p> <p><i>NOTE: The BlackBerry 10 is not supported at this time.</i></p>
<a href="#">iPhone 6 &amp; 6 Plus</a>	<a href="#">iPad Mini</a>											
<a href="#">iPhone 5s, 5c, &amp; 5</a>	<a href="#">iPad 4G</a>											
<a href="#">iPhone 4s</a>	<a href="#">iPad 3G (retina display)</a>											
<a href="#">iPhone 4</a>	<a href="#">iPad 2</a>											
<a href="#">iPhone 3GS</a>												

Please contact Support at 1-877-699-6787 if you have a question about a specific device.

[Compatible eKEY Devices List Click Here](#)

[Supra eKEY Adapter for Apple Products, Click Here](#)

[www.supraekey.com](http://www.supraekey.com)

